

ARCA-SWISS MonoballFix System

802255 Cameraplate monoball@Fix compact

802260 Cameraplate monoball@Fix 32 universal

802262 Cameraplate monoball@Fix Leica M2 -> M7

802265 Cameraplate monoball@Fix 48 universal

802289 Cameraplate Variokit⁽⁴⁾ universal

802270 Cameraplate monoball@Fix SLR index⁽³⁾

802273 Cameraplate monoball@Fix 55 Hasselblad, Leica M8-M9-M240, Olympus E30

802277 Cameraplate monoball@Fix Pentax 645D, 67, 67II

802287 Cameraplate Variokit⁽⁴⁾ Compact

802285 Cameraplate Variokit⁽⁴⁾ Mamiya

802296 Spacer mono ball@Fix Variokit 3mm with screw

802297 Spacer mono ball@Fix Variokit 6mm with screw

802290 Cameraplate Variokit⁽⁴⁾ SLR index⁽³⁾

802292 Cameraplate Variokit⁽⁴⁾ Hasselblad

802295 Stop-plate Kit monoball@Fix

802299 Connection angle

802288 Cameraplate Variokit⁽⁴⁾ SLR for Canon 1D-series ; Nikon D4-series / D3-series & DSLR's with battery-grip

802257 Cameraplate monoball@Fix 35 anti-twist lip

802282 Cameraplate 300 monoball@Fix

802281 Cameraplate 200 monoball@Fix

802280 Cameraplate 150 monoball@Fix

802283 Cameraplate 100 monoball@Fix

802284 Cameraplate 75 monoball@Fix

802320.1 Quick-Link Disk only

802320.2 Quick-Link Base only

802320 Quick-Link Set (incl. 1 base 3/8" + 1 disk 3/8")

802272 Cameraplate monoball@Fix SLR index 2⁽²⁾ (2) For Nikon D850 / D810 / D800, Nikon Z, Fujifilm X-T3, Canon 5D mark IV / mark III / 5Ds

802310 monoball@Fix panoramic Quickset device 1/4" - 3/8"

802310.1 monoball@Fix panoramic double Quickset device

802308.3⁽¹⁾ L -bracket Dual-Base Classic

802308.4⁽¹⁾ L -bracket Dual-Base⁽⁴⁾ FlipLock®

802308.5 L -bracket Dual-Base⁽⁴⁾ monoball@Fix

802304.1 mini L -bracket Dual-Base⁽⁴⁾ anti-twist lip

802304.2 Fuji GFX 50S mounting plate for 802304 series

802304 mini L -bracket Dual-Base⁽⁴⁾ rubberized

802012 Quickset device monoball@Fix 1/4" - 3/8"

802027 Quickset device monoball@Fix to mount DSLR on Function carrier

802002⁽¹⁾ Quickset device Classic with 1/4" - 3/8"

802010⁽¹⁾ Quickset device FlipLock® with 1/4" - 3/8"

802030⁽¹⁾ Quickset device FlipLock® to mount DSLR on Function carrier

802013 Quickset base (for mounting Quickset on Cameraplate and Carrier monoball@Fix system)

052010 Carrier monoball@Fix system

041036 Bench 200 monoball@Fix (to mounting on Camera-plate)

041035 Bench 150 monoball@Fix (to mounting on Cameraplate)

units=millimeters 02/2019

(1) Accepts both monoball@Classic and monoball@Fix camera plates

(3) For Canon 7D series / 6D / 5D series / 50D ; Nikon D810 / D800 / D700 / D300
Sony a 900 / 850 ; Sony A7 1st gen ; Fujifilm GFX 50S

(4) The Variokit system allows to mount longer base Cameraplates

All cameraplate monoball@Fix are compatible with monoball@Fix and monoball@Classic quickset devices