

ARCA-SWISS monoball® fix

802262 Cameraplate monoball®Fix Leica M2 -> M7

802294 Lensplate 100 monoball®Fix

802273 Cameraplate monoball®Fix 55 Hasselblad ; Leica M8-M9; Olympus E30

802270 Cameraplate monoball®Fix SLR index (**) 60

802292 Cameraplate monoball®Fix Hasselblad Variokit

802285 Cameraplate monoball®Fix Mamiya Variokit

802260 Cameraplate monoball®Fix 32 universal

802265 Cameraplate monoball®Fix 48 universal

802282 Cameraplate 300 monoball®Fix

802281 Cameraplate 200 monoball®Fix

802280 Cameraplate 150 monoball®Fix

802283 Cameraplate 100 monoball®Fix

802012 monoball®Fix quickset device 1/4"

802025 monoball®Fix quickset device upgrade for p0 1/4"

802026 monoball®Fix quickset device upgrade for monoball® Z-series, p1 and Cube

802027 monoball®Fix quickset for Carrier universal and M-two

802013 Quickset base (for mounting Quickset on Cameraplate)

802015 N (*) Quickset device classic with screw to convert a monoball

802002 N (*) Quickset device classic round with 1/4" - 3/8"

802019 N (*) Quickset device FlipLock with screw to convert a monoball

802010 N (*) Quickset device Flip-Lock round with 1/4" - 3/8"

802040 (*) Tilting device for p1

041036 Bench 200 monoball®Fix

041035 Bench 150 monoball®Fix

802299 Connection angle

052006 Carrier universal.

802308 L-Bracket monoball®Fix

802310 monoball®Fix panoramic Quickset device 1/4" - 3/8"

802310.1 monoball®Fix panoramic Double Quickset device

(**) for Canon 5D / 50D ; Nikon D700 / D300 ; Sony Alpha 850 / 900

(*) Accepts both Classic and monoball®Fix cameraplates

08/2010

monoball®Fix ist das universellste programm. Die befestigungsplatten des systems sind ultraleicht und multifunktional. Es bieten sich eine vielzahl von möglichkeiten, um kameras mit optischer bank, L-Bügel oder für panoramen zu montieren ... alles mit einem universellen system.

Es stehen drei verschiedene schnellspannvorrichtungen zur auswahl: classic, das flipLock oder die neue version monoball®Fix. Die beiden versionen classic und flipLock bestehen aus einem profil mit einer doppelten schwalbenschwanzführung: oben kann die schnellspannplatte classic eingesetzt werden, unten die monoball®Fix. ARCA-SWISS kameras können ohne zwischenbefestigung direkt auf den stativkopf montiert werden.

The monoball®Fix is the most universal solution. The system's camera plates are ultra light and multi-function. It offers endless possibilities for installing optical benches (camera rails), L-Brackets, additional device, etc! There is a choice of 3 locking systems: the classic, the flipLock or the new monoball®Fix. The Classic and flipLock systems are equipped with a double dovetail so that you can fit the Classic camera plates in the upper dovetail and the monoball®Fix cameraplates in the lower to the top and the monoball®Fix to the bottom. Furthermore, ARCA-SWISS cameras can be fitted directly onto the tripod head without the need for a fixing plate.