

# ARCA-SWISS monoball® fix

**802262** Cameraplate monoball®Fix Leica M2 -> M7

**802294** Lensplate 100 monoball®Fix

**802273** Cameraplate monoball®Fix 55 Hasselblad ; Leica M8-M9; Olympus E30

**802270** Cameraplate monoball®Fix SLR index (\*\*) 60

**802292** Cameraplate monoball®Fix Hasselblad Variokit

**802285** Cameraplate monoball®Fix Mamiya Variokit

**802260** Cameraplate monoball®Fix 32 universal

**802265** Cameraplate monoball®Fix 48 universal

**802282** Cameraplate 300 monoball®Fix

**802281** Cameraplate 200 monoball®Fix

**802280** Cameraplate 150 monoball®Fix

**802283** Cameraplate 100 monoball®Fix

**802288** Cameraplate monoball®Fix SLR Variokit for Canon 1D-series ; Nikon D3-series

**802290** Cameraplate monoball®Fix SLR index (\*\*) Variokit

**802012** monoball®Fix quickset device 1/4"

**802025** monoball®Fix quickset device upgrade for p0 1/4"

**802026** monoball®Fix quickset device upgrade for monoball® Z-series, p1 and Cube

**802027** monoball®Fix quickset for Carrier universal and M-two

**802013** Quickset base (for mounting Quickset on Cameraplate)

**802015 N (\*)** Quickset device classic with screw to convert a monoball

**802002 N (\*)** Quickset device classic round with 1/4" - 3/8"

**802019 N (\*)** Quickset device FlipLock with screw to convert a monoball

**802010 N (\*)** Quickset device Flip-Lock round with 1/4" - 3/8"

**802040 (\*)** Tilting device for p1

**041036** Bench 200 monoball®Fix

**041035** Bench 150 monoball®Fix

**802299** Connection angle

**052006** Carrier universal.

**802308** L-Bracket monoball®Fix

**802310** monoball®Fix panoramic Quickset device 1/4" - 3/8"

**802310.1** monoball®Fix panoramic Double Quickset device

(\*\*) for Canon 5D / 50D ; Nikon D700 / D300 ; Sony Alpha 850 / 900

(\*) Accepts both Classic and monoball®Fix cameraplates

08/2010

monoball®Fix ist das universellste programm. Die befestigungsplatten des systems sind ultraleicht und multifunktional. Es bieten sich eine vielzahl von möglichkeiten, um kameras mit optischer bank, L-Bügel oder für panoramen zu montieren ... alles mit einem universellen system.

Es stehen drei verschiedene schnellspannvorrichtungen zur auswahl: classic, das flipLock oder die neue version monoball®Fix. Die beiden versionen classic und flipLock bestehen aus einem profil mit einer doppelten schwalbenschwanzführung: oben kann die schnellspannplatte classic eingesetzt werden, unten die monoball®Fix. ARCA-SWISS kameras können ohne zwischenbefestigung direkt auf den stativkopf montiert werden.

The monoball®Fix is the most universal solution. The system's camera plates are ultra light and multi-function. It offers endless possibilities for installing optical benches (camera rails), L-Brackets, additional device, etc! There is a choice of 3 locking systems: the classic, the flipLock or the new monoball®Fix. The Classic and flipLock systems are equipped with a double dovetail so that you can fit the Classic camera plates in the upper dovetail and the monoball®Fix camera plates in the lower to the top and the monoball®Fix to the bottom. Furthermore, ARCA-SWISS cameras can be fitted directly onto the tripod head without the need for a fixing plate.